

Proper installation is essential. Please take a moment to review these installation instructions before you begin to install these components on your motorcycle. The removal and installation of air suspension products should only be performed by a fully qualified, ASE Certified, professional.

It is equally important to be aware of all necessary safety measures while installing your new shock can kit. This includes proper lifting and immobilizing of the motorcycle and isolation of any stored energy to prevent personal injury or property damage.

"Elevate Your Ride"



Arnott® is committed to the quality of its products. If you have a question or problem with any Arnott product, please contact Arnott by calling **800-251-8993** during normal business hours or email techassistance@arnottinc.com. (In the EU please call +31 (0)73 7850 580 or email info@arnotteurope.com).

Installation Manual

K-3260, K-3261 ULTIMATE RIDE/SMOOTH RIDE SHOCK CAN KIT



BILL OF MATERIALS K-3260 - ULTIMATE & SMOOTH RIDE SHOCK CAN KIT, BLACK

21-12815

| QTY | PART NO. | DESCRIPTION |
|-----|-------------|---|
| 2 | 29-9294-014 | SHOCK CAN, BLACK |
| 1 | 11-MC-CAN | K-3260 & K-3261 INSTALLATION INSTRUCTIONS |

BILL OF MATERIALS K-3261 - ULTIMATE & SMOOTH RIDE SHOCK CAN KIT, CHROME

21-12816

| QTY | PART NO. | DESCRIPTION |
|-----|-------------|---|
| 2 | 29-9294-024 | SHOCK CAN, CHROME |
| 1 | 11-MC-CAN | K-3260 & K-3261 INSTALLATION INSTRUCTIONS |

SHOCK CAN INSTALLATION

1. REMOVE THE SHOCKS FROM MOTORCYCLE. THE AIR SPRING MUST BE COMPLETELY DEFLATED AND THE SHOCK MUST ALSO BE FULLY EXTENDED.
2. GRASP THE TOP OF THE SHOCK AND UNSCREW THE CAN IN A COUNTER CLOCKWISE DIRECTION FROM THE SHOCK TOP. (FIGURES 1, 2)



FIGURE 1



FIGURE 2

3. SCREW THE NEW CAN ONTO THE SHOCK UNTIL HAND TIGHT. (FIGURES 3, 4)



FIGURE 3



FIGURE 4

4. INSTALLATION COMPLETE.